



## HG100/200 INSTALLATION GUIDE

### Preparation

Howe Green drainage channels will require a recess in the slab nominally 300mm wide and 50mm deeper than the overall depth of the channel.

### Assembly/Installation

The channel sections should now be positioned alongside the trench using drawing if provided, then starting from the drain outlet (ensuring proper connection to the drain), the first channel section should be positioned ensuring that it is adjusted to the correct line and level using the adjustable feet and mortar as required. The next section should then be positioned, once loosely in position the two sections of channel should be bolted together using the bolts provided, making sure that the seal is not damaged and ensuring that the correct line and level is maintained.

This should be continued until the entire assembly is complete. Once complete a water leakage test should be carried out before backfilling.

### Backfilling

Before backfilling, the gratings (if HG100) should be put into position, using the spacers provided between the grating and the channel so that a gap is maintained. The area surrounding the channel should now be backfilled with either concrete or a good quality screed that is compacted well to ensure that there are no voids formed, being careful not to move the assembly. Once this has been completed any cement based product that has been spilled onto the grating should be cleaned off as soon as possible to avoid damage.

### Cleaning

The gratings (if fitted) should be removed and the channel thoroughly cleaned. Then all of the gratings should be replaced.

**Howe Green Limited**  
Marsh Lane, Ware  
Herts. SG12 9QQ

**T:** +44 (0)1920 463230  
**F:** +44 (0)1920 463231  
**E:** [info@howegreen.co.uk](mailto:info@howegreen.co.uk)  
**W:** [www.howegreen.co.uk](http://www.howegreen.co.uk)